

PWC Cover Cleaning Instructions

Cover fabric performance can be severely affected by dirt that builds up on and within the material, creating a “wicking” effect where it actually helps pull water through the fabric, nullifying any water resistant properties the fabric may have had. Cleaning your cover will help to keep your PWC clean and to increase the service life of the cover.

NEVER...Clean a PWC cover in a washer with a center agitator.

NEVER...Use fabric softener.

NEVER...Dry the cover in a dryer.

- 1 - Using a large commercial washer without agitator, wash the cover using 1/4 cup of Simple Green All-Purpose Cleaner. Put the cover in the washer and pour the cleaner in the tub after it's filled with warm water or pour it directly in the machine (some wall mounted commercial units), then put in the cover and start the machine .
- 2 - Rinse the cover twice (2X) to remove all the cleaner.
- 3 - Hang to air dry (or you can install it on your PWC and let it dry).

You can also “spot clean” a cover on the PWC.

- 1 - Mix one ounce Simple Green All-Purpose Cleaner per quart of warm water.
- 2 - Spray or sponge onto cover and work it into the dirty area.
- 3 - Rinse with plain water (until no suds) and allow to air dry.



Simple Green is available in most world markets. If you have any questions, contact them at 1-800-228-0709 (USA) or visit their web-site www.simplegreen.com



If you have additional questions regarding the use or cleaning of your cover, please contact Covercraft Customer Service at 1-800-866-8621 (USA) M-F, 9AM to 4PM CST, or by email at sales@covercraft.com